


Sensor Activated Clean Dry™ Hand Dryer



| Item | Part | Description |
|------|------------|------------------------------|
| 1 | THP3065 | Filter |
| 2 | THP3067 | Water Tray |
| 3 | THP3082#SS | Front Cover |
| 4 | THP3069 | Controller Assembly |
| 5 | THP3083 | LED |
| 6 | THP3071 | LED Harness |
| 7 | THP3072 | Motor Assembly |
| 8 | THP3073 | Thermistor |
| 9 | THP3075 | Gasket, Motor Cover |
| 10 | THP3076 | Gasket, Air Nozzle |
| 11 | THP3077 | Nozzle |
| 12 | THP3078 | Terminal Block, Power Supply |

| Item | Part | Description |
|------|---------|--------------------------|
| 13 | THP3079 | Under Cover Assembly, D. |
| 14 | THP3084 | Tarpaulin |
| 15 | THP3090 | Mounting Bracket (Upper) |
| 16 | THP3091 | Mounting Bracket (Lower) |
| 17 | THP3034 | Screw |
| 18 | THP3035 | Tapping Screw (DIA4X16) |
| 19 | THP3086 | Tapping Screw(DIA4X18) |
| 20 | THP3087 | M Screw (M4x6) |
| 21 | THP3088 | M Screw (M4x12) |
| 22 | THP3089 | M Screw/VAND (M4x8) |
| 23 | THP3052 | Hex Wrench/VAND/HDR |