


Sensor Activated Clean Dry™ Hand Dryer



Item	Part	Description
1	THP3065	Filter
2	THP3067	Water Tray
3	THP3082#SS	Front Cover
4	THP3069	Controller Assembly
5	THP3083	LED
6	THP3071	LED Harness
7	THP3072	Motor Assembly
8	THP3073	Thermistor
9	THP3075	Gasket, Motor Cover
10	THP3076	Gasket, Air Nozzle
11	THP3077	Nozzle
12	THP3078	Terminal Block, Power Supply

Item	Part	Description
13	THP3079	Under Cover Assembly, D.
14	THP3084	Tarpaulin
15	THP3090	Mounting Bracket (Upper)
16	THP3091	Mounting Bracket (Lower)
17	THP3034	Screw
18	THP3035	Tapping Screw (DIA4X16)
19	THP3086	Tapping Screw(DIA4X18)
20	THP3087	M Screw (M4x6)
21	THP3088	M Screw (M4x12)
22	THP3089	M Screw/VAND (M4x8)
23	THP3052	Hex Wrench/VAND/HDR